

FRONT-HIP POCKET FOR PANTS

OTTOBRE design®
7/2017, design 7

PATTERN PIECES

- pants front
- pants back
- pocket bag
- corner piece
- pocket facing



1. Pin and stitch diagonal edge of corner piece to pocket bag right sides together, observing pattern markings.

2. Turn corner piece right way up and topstitch seam close to seamline, placing stitching on corner piece. Machine-baste edges of corner piece to top and side edges of pocket bag.

Pin and stitch pocket facing to opening edge of pocket bag. Fold seam allowances toward facing and topstitch seam close to seamline.

3. Pin and stitch pocket bag to edge of pocket opening on pants front right sides together. Understitch seam allowances to pocket bag.

4. Fold pocket bag to wrong side and topstitch edge of pocket opening 10 mm from edge.

5. Stitch bottom of pocket as a French seam: First fold pocket bag in half wrong sides together and stitch bottom of pocket with 6 mm seam allowance.

6. Then fold pocket bag in half right sides together and stitch bottom of pocket again, concealing seam allowances within seam.

7. Machine-baste top and side edges of pocket to waist and side seam allowances of pants front.

8. Pin pants front and back right sides together and stitch side seam. Fold seam allowances toward pants back and topstitch side seam close to seamline from waist edge to bottom edge of front-hip pocket. Stitch bar-tack at bottom corner of front-hip pocket opening.



OTTOBRE

